# TECHNICAL INFORMATION



0

# **DETERGENTS/DISINFECTION DETERGENTS** · with and without dosing technology

# MAXIMO LIQUID FORTE



### Art. No. 600.513 20 kg canister

- liquid single laundry detergent without bleach
- on basis of well selected tensides
- concentrated washing power with immediately effect
  cleans and cares all textiles such as fine and coloured laundry,
- synthetics, mixed fabrics and white laundry not suitable for wool
- ideal for white laundry in combination with PES 32 (60 °C)

#### **APPLICATION RANGE:**

Washes and cares all textiles such as fine and coloured laundry, synthetics, mixed fabrics and white laundry – except wool. Ideal for white laundry in combination with PES 32 (60  $^{\circ}$ C).

#### INSTRUCTIONS FOR USE AND DOSAGE:

Maximo Liquid Forte to be dosaged acc to machine size and water hardness - to the main wash cycle section - Following dosage table.

Dosing				washing-solution ratio	Disinfection temperature	exposure time
	RKI	MAXIMO LIQUID FORTE	2-4g	1:5	70 °C	10 min
H		PES 32	2g			
	VAH	MAXIMO LIQUID FORTE	2-4g	1:5	60 °C	15 min
V		PES 32	2g			

Can be connected to automatic dosage technology

If improperly applied - and for claims resulting from such improper handling - there will be no legal claims accepted.

## **TECHNICAL DATA:**

Form:	amber liquid
Odour:	scented
Density:	1040 g/l
pH-value in delivery state:	

#### **INGREDIENTS:**

Below 5 %:	anionic surfactants, phosphonates
5-15 %:	
15-30 %:	
Contains:	perfumes, enzymes (protease, amylase), optical brighteners
	at least one year in original containers
	reparation comply with the biodegradability criteria as laid
down in Regulation (EC) No. 648/2	2004 on detergents.

LABELLING:

	Hazard statements: H319: Causes serious eye irritation.*
Warning	<ul> <li>Precautionary statements:</li> <li>P102: Keep out of reach of children.</li> <li>P264: Wash hands thoroughly after handling.</li> <li>P305+351+338: IF IN EYES: Rinse cautiously with water for several minutes.</li> <li>Remove contact lenses, if present and easy to do. Continue rinsing.</li> <li>P337+313: If eye irritation persists: Get medical advice.</li> <li>* Classification: DetNet</li> </ul>

TRANSPORT: No dangerous good in sense of these transport regulations (ADR).

#### KLEEN PURGATIS GmbH

## Headquaters

Dieselstraβe 10 D-32120 Hiddenhausen Fon +49 (0) 5223 9970-40 Fax +49 (0) 5223 9970-50 info@kleen-purgatis.de

#### Sales Department International Firststrasse 15

CH-8835 Feusisberg Fon +41 (0) 44 515 35 61 Fax +41 (0) 44 515 35 69 info@kleen-purgatis.ch

#### www.kleen-purgatis.de

02.09.2016

Date: (

An Affiliated Company of the BUDICH GROUP