# TECHNICAL INFORMATION



# DETERGENT BOOSTER, FABRIC RINSE AND LAUNDRY ADDITIVES

# **PRODIL**

Stain Remover Salt





Art. No. 224.551 5 kg bucket

- oxygen active laundry detergent booster and fat solvent in combination with heavy duty detergent
- produces stainless white laundry and brilliant coloured laundry
- removing grey haze and yellowing from all white textiles
- stains originating from grass spinach, red wine, tea, coffee and cocoa will be easily removed
- does not contain fibre damaging substances

#### **APPLICATION RANGE:**

Laundry booster in combination with heavy duty detergents for stainless white wash and for brilliant coloured laundry. Not for use on wool and silk fabrics.

## **INSTRUCTIONS FOR USE AND DOSAGE:**

Simply add Prodil to main wash cycle jointly with detergent. Depending on degree of soiling add between 10-20 g/kg dry laundry. Strongly soiled laundry should be presoaked prior to machine wash – in Prodil enriched water – or add Prodil into the pre-wash cycle!

Conduct a material compatibility test on a small area of the coloured laundry before starting.

Always follow the cleaning instructions of the manufactorer.

If improperly applied - and for claims resulting from such improper handling - there will be no legal claims accepted.

## **TECHNICAL DATA:**

Form:	white powder
Odour:	neutral
Bulk Density:	950 g/L
pH-Value in aqueous solution:	11

### **INGREDIENTS:**

Below 5 %:	non-ionic surfactants, polycarboxylates
15-30 %:	oxygen-based bleaching agents
Contains:	Enzyme, (Lipase, Protease, Amylase)
Stability:	at least one year in original containers

The surfactants contained in this preparation comply with the biodegradability criteria as laid down in Regulation (EC) No. 648/2004 on detergents.

#### LABELLING:



**Hazard statements:** H319: Causes serious eye irritation.

**Precautionary statements:** P101: If medical advice is needed, have product container or label at hand. P102: Keep out of reach of children. P264: Wash hands thoroughly after handling. P280: Wear eye protection. P305+351+338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P337+313: If eye irritation persists: Get medical advice.

TRANSPORT: No dangerous good in sense of these transport regulations (ADR).

# KLEEN PURGATIS GmbH

#### Headquaters

Dieselstraβe 10 D-32120 Hiddenhausen Fon +49 (0) 5223 9970-40 Fax +49 (0) 5223 9970-50 info@kleen-purgatis.de

#### Sales Department International

Firststrasse 15 CH-8835 Feusisberg Fon +41 (0) 44 78686-68 Fax +41 (0) 44 78686-69 info@kleen-purgatis.ch

#### www.kleen-purgatis.de

An Affiliated Company of the BUDICH GROUP